TABLE 2. Signal line space and trace widths.

NUMBER OF TRACES	FORMULA
1	$C_A \geq [2 \times (\text{space width})] + \text{trace width}$
2	$C_A \geq [3 \times (\text{space width})] + [2 \times (\text{trace width})]$
3	$C_A \geq [5 \times (\text{space width})] + [3 \times (\text{trace width})]$